



## Rear Anti Sway Bar Install with vehicle under load (4 Post hoist or Car ramps)

- A.** Connect mount plates to sway bar arms. Plates on top of arms, as in Pic '1'. "Rear" ('U' bolt) plate at "start of bend"
- B.** Position sway bar as in Pic '2'. With mount plates under each trail arm. Move bar forward as much as possible making sure even distance on both sides.



- C.** Connect each plate to trail arm 'U' channel by centre punching up through remaining hole in each plate. Drill 3/8" hole and insert long bolt supplied with the large flat washer and self lock nut on top. Check all bolts are tight / secure.

ALSO MANUFACTURED: Uprated (24" diam.) Front Anti Sway Bar

**CAMBER** & **CASTER** Top Strut Mounts - **STAGE 1** (STREET), **STAGE 2** (STREET/RACE), **STAGE 3** (FULL RACE)